



PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.




LUNA 40



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



$AB=CD$ LUNA 40





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 2%

ATTACH FOUNDATION BEAMS
WITH SCREWS.


LUNA 40

- 5×70 × 4
- 6×140 × 14
- $\varnothing 4 \text{ mm}$
- $\varnothing 5 \text{ mm}$




LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

5×70 \times 6 6×140 \times 12
 $\varnothing 4$ mm $\varnothing 5$ mm



4/24

LUNA 40





THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **4%**

ATTACH THE FIRST ROW OF WALL LOGS INTO THE BOTTOM LOGS WITH SCREWS.


LUNA 40

- 5×70 × 6
- 6×140 × 5
- $\varnothing 4$ mm
- $\varnothing 5$ mm





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

LUNA 40




SLIDE THE **DOORS** IN,
ATTACH THE **HANDLES**.

LUNA 40




DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

LUNA 40



SLIDE THE WINDOW IN,
ATTACH THE HANDLE.

LUNA 40




SLIDE THE **WINDOWS** IN.

LUNA 40



1 LG-5






CW4L

CW4R

INSTALL THE MIDDLE WINDOW,
INSERT CM1 BETWEEN THE WINDOWS
AND ATTACH WINDOWS TO CM1
WITH SCREWS.



4x40
× 16



ATTACH **LATHS** (LTH1) INTO
WINDOWS AND INTO **CM1**
WITH SCREWS.

4x40
× 16

LUNA 40





INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

LUNA 40

6x140
× 6



Ø 5 mm



INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.

LUNA 40




6x140
× 9
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH 6 SCREWS, 3 **INTO** EACH NEXT. SAW THE LAST **BOARD** TO MAKE IT FIT.

LUNA 40


4x50  × 348



FOR THE FASCIA TRIMS
INSERT **SCREWS** AFTER EVERY
0,5 METERS.

4x40
× 52

LUNA 40




EAVES EDGES GO ON TOP
OF THE ROOFING*.

*(NOT INCLUDED)

4x40
× 32



Ø 3 mm



LUNA 40

EE


RF



ATTACH ROMBS WITH SCREWS.




LUNA 40

4x40
× 4





14 SCREWS INTO THE FIRST FLOORBOARD,
7 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50  × 266



SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.



1,4×40
× 30



DRILL THROUGH THE WALL, HOLES MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.



M8x90 × 20

Ø 8 mm




IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90°.

LUNA 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

LUNA 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

LUNA 40

